

## SET THE TOP ON THE CAGE

Line up the hole in the front with the front hole in the roll cage.



**1A.** For Easier Installation- We remove the cover on the front of the cage. 2 ½" x ¼" bolt (underside)



**1B.** Add ½" Spacers.



**2A. & 2B.** You will need to drill the middle mounting holes (1/4" Bit). This is on the middle support bar- FRONT OUTER HOLE (EDGE)

**2C.** Put the 3 ½" x ¼" bolt through the Support Middle Bar of the roll cage.



**3A.** You will need to drill (1/4" Bit) the rear mounting hole, this is located on the rear outer hole of the roll cage. 2 ½" Bolt



**4A. & 4B.** Run the wire down the rear of the roll cage and connect to the battery behind the passenger rear seat.

For any other questions or concerns,  
Please contact us at (903)873-5902  
info@audioformz.com



## 2020 X-3 MAX Install Manual

**We highly recommend the installation of this stereo top to be performed by an authorized AudioFormz dealer. Warranty of stereo top and/or components may be voided if not installed correctly.**

**Hardware Kit:**

**2- 3 ½" x ¼" Bolts (Middle Section)**

**2- 2 ½" x ¼" Bolts (Rear Section)**

**4- Small Washers**

**4- 1 ¼" x ¼" Washers**

**4- ¼" Nuts**

**Full Windshield:**

**2- ½" Spacer**