



General Instruction Manual

Set the top on the Roll Cage

1. Line up the holes already drilled in the front of the top with factory holes. Put the 1 ½" x ¼" bolt thru. The 1 ½" fender washer on top 1" fender washer on the bottom.

2. This is the location for the rear clamp

3. Drill ¼" hole as shown.

4. Install 1 ½" x ¼" bolt with 1 ½" fender washer on the top 1" fender washer on the bottom.

5. Run the power cable down the rear of the roll case. You can drill hole as shown to run the power cable to the battery.

6. Install the fuse holder and terminals. Connect to the battery, under driver's seat.

Materials:

2- Custom Clamps

4 - 1 ½" x ¼" Bolts

4- ¼" Nylon Lock Nuts

4- 1 ¼" Fender Washers (black)

4- Small Flat Washers