



1A. (Front Location) & 1B. SIT THE TOP ON THE ROLL CAGE. LINE THE TOP UP WITH FACTORY MOUNTING LOCATIONS.



1B. (Rear Location)



2. USE THE SMALL BLACK FENDER WASHER AND THE 1 ½" x ¼" BOLT TO MOUNT IN THE FRONT LOCATION.



3. USE THE LARGE BLACK FENDER WASHER AND THE 1 ¼" x ¼" BOLT TO MOUNT IN THE REAR LOCATION.



4A. & 4B. RUN THE POWER WIRE DOWN THE BACK OF THE ROLL CAGE TO THE BATTERY LOCATION. (Under the fender of the driver side rear tire)



4B.



5. CONNECT THE FUSE HOLDER THEN THE LEADS TO THE BATTERY. FUSE HOLDER MUST BE PROPERLY INSTALLED WITHIN 18" OF BATTERY DURING STEREO TOP INSTALLATION! Warranty of stereo top and components may be voided if fuse holder is not used. See pictures illustrating proper installation of fuse holder. Contact us at 903-873-5902 with any questions concerning installation or if missing any installation



HONDA TALON

We highly recommend the installation of this stereo top to be performed by an authorized AudioFormz dealer. Warranty of stereo top and/or components may be voided if not installed correctly.

HARDWARE KIT:

(2) 1 ½" x ¼" Bolts

(2) 1 ¼" x ¼" Bolts

(2) Large Fender Washer

(2) Small Fender Washers

(4) ¼" Nuts

(4) Small Washer

Any questions call the Office 903-873-5902 or info@audioformz.com