

# MULE 4010

## 1. THERE ARE 6 PREDRILLED HOLES IN THE TOP.

- THE FRONT 2 HOLES ARE 1  $\frac{3}{4}$ " CLAMPS.
- THE MIDDLE AND REAR HOLES GET THE 1  $\frac{7}{8}$ " CLAMPS.
- PUT THE CLAMPS ON THE ROLLCAGE THEN SET THE TOP ON THE ROLLCAGE. INSTALL THE HARDWARE.

## 2. RUN THE POWERWIRE TO THE BATTERY.

- SECURE THE WIRE WITH THE ZIP TIES PROVIDED.
- INSTALL THE FUSE HOLDER.

DO NOT PUT IN THE FUSE.

## 3. INSTALL THE TERMINALS AND CONNECT TO THE BATTERY.

- RED POSTIVE BLACK NEGATIVE
- NOW INSTALL THE FUSE AND POWER UP THE TOP.



# MULE 4010

**We highly recommend the installation of this stereo top to be performed by an authorized AudioFormz dealer. Warranty of stereo top and/or components may be voided if not installed correctly.**

HARDWARE:

- (4) 1 7/8" CLAMPS
- (2) 1 3/4" CLAMPS
- (4) 1 1/2" X 1/4" BOLTS
- (4) BLACK FENDER WASHERS
- (4) SILVER WASHERS
- (4) 1/4" NYLON LOCKING NUTS
- (1) FUSE HOLDER WITH TERMINALS