



# **PIONEER 700 Instruction Manual**

## **Materials:**

- 4- 1 5/8 Clamps**
- 2 -1/4" x 1/2" Long Bolts**
- 2 -Self –Tapping Screws**
- 2-Nylon Nuts**
- 4- Fender Washers (black)**
- 2-Small Flat Washers**

**For any other questions or concerns,  
Please contact us at (903) 873-5902  
[infor@audioformz.com](mailto:infor@audioformz.com)**



the top on the roll cage  
These the holes in the front of the



2. Using the Clamps provided Line up the holes and Install the Clamps using 1/4" Bolts



3. The white dots in the rear have Metal Plates under the Fiberglass Drill with in 1" from the White Dot



4. Using Self- Tapping Screws Install Clamps



5. Run the Wire down the Roll Cage to the Battery



6. Using Terminals Provided and Fuse Holder Connect the Battery