



# AUDIOFORMZ RZR 170 INSTRUCTION MANUAL



## Supplied Hardware:

Front – Two (2) 1.5” Black Bolts, Two (2) Black Fender Washers, Two (2) Lock Nuts, Two (2) 1 ¼” Silver Washers, Two (2) 1 ¼” Clamps

Back – Two (2) 1.5” Black Bolts, Two (2) Black Fender Washers, Two (2) Lock Nuts, Two (2) 1 ¼” Silver Washers, Two (2) 1 ¼” Clamps



**1**

Set the stereo top on top of the factory roll cage. Line up the clamp with the pre drilled hole in the front of the top. Put the provided 1.5” black bolt followed by a black fender washer through the hole on the top of your roof and clamp. Start the silver washer and lock nut on the bolt, but do not fully tighten.

Repeat on opposite side in front.



**2**

Move to the rear of the top. Repeat step 1 with provided hardware.

Once all clamps and bolts are in place and top is even on the roll cage, please go around and tighten the bolts down the rest of the way.



**3**

Run the power cable down the back of the driver side roll cage. Connect the positive and negative wires to the battery under the seat.

For any other questions or concerns,  
Please contact us at  
(903) 873-5902

[info@audioformz.com](mailto:info@audioformz.com)

[www.audioformz.com](http://www.audioformz.com)

[www.audioformz.com](http://www.audioformz.com)