



1. THERE WILL BE PREDRILLED HOLES IN THE FRONT OF THE TOP.



2A. & 2B.

2 A. & B. LINE THE HOLES UP WITH THE FRONT MOUNTING POINTS OF THE ROLL CAGE. THEN INSTALL THE LIGHT BAR AT THIS TIME USING THE HARDWARE PROVIDED FENDER WASHERS, 1/4" BOLTS AND NYLON LOCKING NUTS.



3A. & 3B.



3C.

3A, 3B & 3C. MAKE SURE THE REAR OF THE TOP IS CENTERED. DRILL THE REAR MOUNTING HOLE LOCATED AT THE REAR MOUNTING LOCATION ON THE CAGE. INSTALL THE MOUNTING HAREWARE IN THE REAR HOLES. FENDER WASHERS, 1/4" BOLTS, SILVER WASHERS, AND LOCKING NUTS.



4. DRILL THE MOUNTING HOLES AT THE MOUNTING LOCATIONS AT THE CENTER OF THE CAGE. THERE ARE TWO HOLES ON EACH SIDE. **(DRILL THE OUTER HOLE)** INSTALL WITH THE HARDWARE PROVIDED. FENDER WASHERS, 1/4" BOLTS, SILVER WASHER, AND NYLON LOCKING NUT.



5.



RUN THE POWER WIRE DOWN THE DRIVER SIDE MIDDLE BAR OF THE ROLL CAGE. BATTERY IS UNDER THE DRIVER'S SEAT. INSTALL THE FUSE HOLDER AND CONNECT THE BATTERY.

Have any questions or concerns call 903-873-5902 or info@audioformz.com.

HARDWARE:

4- SMALL SILVER WASHERS

6- 1 ¼" x ¼" BOLTS

6- 1 ¼" BLACK FENDER WASHERS

2- 1" BLACK FENDER WASHERS

6-¼" NYLON LOCKING NUTS



RZR 4 PRO-R

We highly recommend the installation of this stereo top to be performed by an authorized AudioFormz dealer. Warranty of stereo top and/or components may be voided if not installed correctly.