

## Set the Top on the Roll Cage



1. Run the bolt thru the top and bracket of the roll cage. Use the fender washer provided. This is also the bolt you will use to mount the light bar.



2. Pull down the plastic cover under the roll cage to place the nut and washer on the underside.



3. You will need to drill (1/4" Bit) the rear mounting hole, this is located on the rear outer hole of the roll cage. 2 1/2" Bolt

4. Install the washer and the nut. Do Not Over Tighten!



5. Run the power cable down the passenger side to the battery.

Install the fuse holder. Connect to the battery.



### Installing a Front Full Windshield

Install the 1/2" Spacer using the 2 1/2" x 1/4" Bolts in the Front Light Bar Mount (Front Hole Locations).

Have any questions or concerns call 903-873-5902 or [info@audioformz.com](mailto:info@audioformz.com)



# AUDIOFORMZ

## Can Am X-3 Install Manual

**2-1 ¼" Fender Washers**

**2- 1" Flat Washer**

**2- ¼" x 2 ½" Bolts (Rear Mounting)**

**2- Nuts**

**Installing Full Windshield:**

**2- 2 ½" x ¼" Bolts**

**2- ½" Spacer**